

# Burner Pipe Distributor 7 Pattern

Bent Tip Electrode PN 089092


Burner Plate 545  
LH 096556 RH 096557

Shielded Style Electrode PN 089066  
Burner Plate PN 096499


## Description

The Flynn Distributor Pipe burner provides lateral flame adjustment to equalize product color and moisture across the band. Illustrated below are the various flame patterns available.

- Available in 2" Pipe
- Single Point Adjustment
- Interchangeable with existing pipe burners
- Suitable for use with natural gas, propane and butane



(Bent Tip Electrode Shown)



Level distribution across the entire flame space



Near High FS 1 has a higher output distribution



Far High FS 3 has a higher output distribution




Center High FS 2 has a higher output distribution



Center Low FS 1 & 3 have higher output distribution




Far Low FS 1 & 2 have higher output distribution



Near Low FS 2 & 3 have higher output distribution





**SELECT THE BURNER FIRING AND INLET ORIENTATION**

